

Cornwall Electric Feeder and Station Capacity Map

Stations	Feeders
Remaining Capacity	Remaining Capacity
⊕ 0 to 999 KVA	■ 0 to 3999 KVA
⊕ 1000 to 19999 KVA	■ 4000 to 4999 KVA
⊕ 20000+ KVA	■ 5000+ KVA

This hosting capacity map is provided for information purposes only. Cornwall Electric (CE) doesn't warrant or guarantee the completeness and accuracy of the information for any particular decision making. Users of the map are encouraged to contact CE for further constraints relating to conductor size, phases, and upstream capacity.